



CEILING
LIGHTING
AMBIENCE

S4 TAIFUN

INSTALLATION MANUAL

GENERAL INFORMATION

GENERAL INFORMATION

This assembly manual addresses all metal ceilings manufactured by durlum. The different sections describe the related/relevant products.

durlum is a leading German manufacturer of metal ceilings and cladding elements, mainly made of galvanised sheet steel, aluminium and expanded metal.



The relevant products are described in the marketing and sales documents. They are both acoustically effective, and can also be used as design elements only. Specifically, these products are:

- Acoustic ceilings
- Chilled ceilings
- CHARACTER products

durlum differentiates between a wide range of ceiling systems, for example S1. "S1" stands for system 1 clamping. In this system, there are different nomenclatures that allow a further subdivision of the systems.

All durlum systems are systems of modular design. This applies not only to the substructure but also the ceiling parts that are suspended, locked into place or placed on the substructure.

durlum metal ceilings comply with the standard EN 13964:2007 and are CE-certified.

Appropriate static certificates are available for special systems marketed by us and for which no general approvals are available, and appropriate designs compliant with EN 13964 have been constructed. durlum lamps comply with standard EN 60598-1 and are CE-certified.

GUIDELINES

These installation instructions have been structured in accordance with the requirement of EN 13964:2007 and describe a proper assembly.

The description does not exempt the user from examining the structural conditions, implementing the building code regulations and observing the information given in the building permit prior to starting assembly. They have priority, but could not be included here.

It is advisable always to draw up assembly diagrams/drawings, to establish the location where assembly is to begin and to establish the required suspension points for the relevant ceiling system prior to starting assembly.

STRUCTURAL PRECONDITIONS

Metal ceilings may usually be installed as soon as the building is swept clean, but at least when all wet work in the interior has been completed and the building has been closed.

Prior to starting assembly, the suspension points must be checked for their usability, and load introduction into the building must be guaranteed.

When using wall mounting points, such as brackets or wall anchors, the load-carrying capacity of the wall in question must be checked.

If ceiling elements rest on brackets, possible wall movements must be taken into account.

Only anchors for which a general building supervisory approval is available may be used, and their minimum extraction force must be greater than 100kg. The anchors must be mounted as specified by the relevant anchors manufacturer. We recommend performing regular tensile stress tests, to verify that anchors have been set correctly.

durlum metal ceilings are dimensioned such that they carry their own weight of the system construction plus a surface load amounting to 40N/m². Higher loads must be taken into account or suspended separately in the construction, and the measures must be adapted to the situation at hand. Usually, built-in components and loads must be suspended separately.

For ceiling systems that do not allow any tolerance compensation within a module,

suitable material expansions must be taken into account.

Building expansion joints and tolerances customary in building construction must be taken into account accordingly.

durlum metal ceilings must always be assembled by expert dry building companies who are capable of assessing the overall situation in the building, the metal ceiling, the cladding surface, as well as the structural conditions and are able to take suitable precautions for ensuring proper assembly.

If parts from different manufacturers are used to assemble the ceiling, the relevant mounting company must provide the certificates required by EN 13964:2007 and must obtain suitable certificates of conformity itself.

Liability for proper selection of the products and system conformity can only be assumed for the systems delivered by durlum.

To prevent the parts from becoming dirty, gloves must be worn during assembly. If the ceiling products are delivered laminated with a protective film, they must be protected from exposure to UV radiation [sunlight], the film must likewise be removed from the goods no later than 4 weeks after delivery, and the storage temperature must not exceed 30°, since otherwise the adhesive on the panel may become hardened, and the protective film can no longer be removed.

STORAGE

durlum metal ceilings are usually delivered on pallets. It is advisable to leave the metal panels on the pallets as long as possible. If the pallets need to be opened, the durlum POLYLAM® should always be placed on its underside.

Storage must be carried out such that damage is excluded.

The assembly of the ceiling panels must not start until all dust-producing work has been completed [swept clean].

durlum products are certified according to ISO 9001 for development, production, sales and also for service. Nevertheless, it is recommended to always subject the metal ceilings immediately to an inspection and to report any complaints right away [usually immediately following delivery or within 3 days]. Visible damage must be noted on the delivery note.

STANDARDS AND REGULATIONS

The relevant regulations applicable at the installation site must be determined by the assembly company in question. The ceilings marketed by durlum conform to EN 13964. This standard also governs fire behaviour in accordance with EN 13501.

APPLICATION

The application of durlum metal ceilings is restricted, unless agreed upon otherwise, to interiors, so that, pursuant to EN 13964, class of use 1, corrosion protection class A, has been defined here as standard. The use of durlum lighting is restricted to interiors. The lighting complies with protection class IP 20, protection class 1 according to EN 60598-1.

Should it become necessary to adjust the metal ceiling panels to the building by cutting, we recommend protecting the cutting edges from corrosion by means of a paint, to maintain the corrosion protection class A.




QUALITY STANDARD

For material properties, dimensions, tolerances, colour deviations, the TAIM Directives [Technical Association of Industrial Metal Ceiling Manufacturers] applies.

MOUNTING SEQUENCE

1. Prepare ceiling- and lighting installation plan or adopt architect's plan.
2. Check ceiling lighting installation plan versus structural conditions.
3. Prepare a bill of materials, including a suitable work plan and retrieval/order of the materials required.
4. Determine the required suspension points in accordance with the classes of use of EN 13964. The corresponding suspension distances for the different systems can be taken from the detailed descriptions of the individual ceiling systems.
5. Establish which generally approved anchor is suitable. Check the raw ceiling and the walls. Mark the anchor mounting holes and drill them. Mount the anchors as specified by the anchor manufacturer and carry out extraction tests using the device recommended by the anchor manufacturer, if necessary.
6. Use the same procedure when mounting the wall brackets, mounting distance about 400–625mm, check the introduction of force into the wall.
7. Shorten intended fastening elements, such as the M6/M8 threaded rod to the intended length or order the correct length and mount it on the raw ceiling.
8. Usually, the panel layout should be started from the centre of the room, in order to be able to compensate the tolerance of the room and cut the panels in half, if necessary. The precise arrangement must always be done on the basis of the ceiling layout plan.
9. durlum metal ceilings are usually provided with a cross support [primary profile].
10. Use the layout plan to determine in which direction the cross reinforcement profiles are laid, either in parallel to the façade [usually] or vertically to the façade. The cross reinforcement profiles should be mounted via a wall anchor or via a diagonal anchoring to prevent an axial movement. The corresponding primary profiles are mounted at right angles to the secondary profiles. To this end, the system-specific connecting elements are used, see system descriptions. The position of the primary profiles is established in the reflected ceiling plan.
11. The metal ceiling panels are often provided with a joint tape [9x3mm], to make for easier tolerance compensation. Should a joint tape be used, the joints must also be re-aligned from time to time, since the joint tape also has tolerances. However, owing to the high production precision, it is also possible to connect the panels without a joint tape by using butt joints or provide them with rubber spacer naps. Always ensure that the joints are aligned.
12. If the panels are placed on a perimeter trim, we recommend our F-bracket as bracket or as stepped F-bracket. The bracket secures the panel and protects it against lifting. The ceiling panel is cut with electric sheet shears [i.e. Treco shears] and adapted to the prevailing room dimensions. When calculating the minimum support area [10mm], the dimensions of possible wall movement should be taken into account.
13. Attachments or other loads are to be mounted separately. For logical reasons these parts are integrated during the mounting process.
14. After completion and pre-acceptance of the ceiling, the sequence of joints should be re-aligned. Soiled ceiling panels should be cleaned to give a perfect result for assembly.

SYSTEM S4 TAIFUN INSTALLATION MANUAL



- 1** Threaded rod M6
- 2** Hook-on carrier U 1005 A
- 3** Self-securing screw connection M6

- 4** Connector U 1044
- 5** L-shaped primary carrier U 1040
- 6** Rectangular metal panel

- 7** Vernier scale
- 8** Securing element U 1073 A

ABBREVIATIONS

AP: Distance of primary profiles U 1040
 AS: Distance of secondary profiles U 1005 A
 AH: Distance of the suspension hangers in axial direction of the primary profile

DISTANCE OF THE SUSPENSIONS ETC.

The following recommendation for the distances of the primary profiles and the suspension points refers only to standard ceilings in indoor applications without additional loads.

Distance of the primary profiles AP according to EN 13964:
 $\leq 1\,000\text{ mm}$

Distance of the secondary profiles AS according to EN 13964:
 Depending on the panel length but $\leq 1\,000\text{ mm}$

Distance of the suspension points AH:
 The distance of the suspension points AH is determined by the corresponding panel length. The L-shaped primary carrier serves mainly for cross bracing.

The maximum force applied to the suspension point may be 200 N. The corresponding suspension parts and dowels must be taken into account.

If it is not possible to specify in advance where the secondary profiles will run, select the distance of the suspension points $AH \leq 1\,000\text{ mm}$.

Load-carrying capacity of the suspension points [tensile loads]:

- Maximum load per vernier suspension: 200 N
- Maximum load per threaded rod M6: 500 N
- Other loads must be verified statically.

Stress class according to EN 13964: Stress class A according to Table 7

PLEASE NOTE

- Use only officially approved dowels.
- The fastening base must be suitable in terms of statics. It must be able to reliably absorb the forces introduced into the construction.

ASSEMBLY OF THE SUSPENSION

Assembly of the wall bracket:

The regular distance for mounting the perimeter trim is max. 500 mm. This regular distance is less, depending on additional loads, the type of wall and special requirements.

1. Level and outline the given ceiling height.
2. Outline the upper edge of the perimeter trim.
3. Mark the drill hole.
4. Drill a hole for the dowel.
5. Secure the perimeter trim with a dowel.
6. Cleanly mitre cut the edges of the perimeter trim profiles.

Installation of the primary profile [U 1040]:

7. Outline the axis grid for the primary and secondary profiles.
8. Define the suspension points.
 - 8.1. The suspension hangers of the primary profile should be mounted as close as possible to the crossing point of the primary and secondary profiles. The maximum distance between the suspension hanger and the secondary profile is 100 mm [also see "Distance of the suspension points AH"].
 - 8.2. Module adapters [cross connectors] may not be mounted at the joint of the primary profiles.
 - 8.3. Keep a distance of at least 400 mm to the joint of the primary profiles.
 - 8.4. The maximum distance of a suspension point from the wall is 500 mm.
9. Drill a hole for the dowel.
10. Mount vernier scale upper part U 1300 or threaded rod M6 with dowels according to the manufacturer's instructions.
11. Cut L-shaped primary carrier U 1040 to the required length.
12. Fasten the vernier scale lower part U 1370 to the suspension points with a self-securing screw connection M6.
13. Place the L-shaped primary carrier U 1040 horizontally, vertically and aligned for the given ceiling height.
14. Secure vernier scale lower part U 1370 to vernier scale upper parts with two vernier scale safety pins U 1372. When using the threaded rod suspension, the threaded rod is guided through the horizontal shank of the L-shaped primary carrier and rigidly fastened with the self-securing screw connection M6.
15. The L-shaped primary carrier connector U 1041 is connected to the joint of the L-shaped primary carrier using a self-securing screw connection M6. Arrange the longitudinal connections of the profiles offset to one another.

16. When adjusting the height, observe the permissible height tolerances according to EN 13964, readjusting it, if necessary.
17. The primary profiles must be connected to the wall at least on one side with the wall bracket U 1042 to exclude any shift in axial direction.

Installation of the secondary profile [U 1005 A]:

18. Outline the predefined axis grid for the secondary profiles at the L-shaped primary carriers.
19. Cut the hook-on carriers U 1005 A to the required length.
20. Mount hook-on carriers to the L-shaped primary carriers U 1040 with module adapter U 1044 and the self-securing screw connection M6.
21. Centre the connector U 401 above the joint of the hook-on carriers U 1005 A and secure it with drilling screws. Required longitudinal connections should be arranged in an offset manner.

ASSEMBLY OF THE CEILING PANELS

1. Wear clean cotton gloves.
2. Remove the protective film from the ceiling panels, if available.
3. Place the ceiling panel with the Z-edge [AS3] on the hook-on carrier U 1005 A or adjacent ceiling panel.
4. Insert the ceiling panel with the hook-on edge [AS6] using the vertical suspension bracket of the hook-on carrier.
5. Lower the ceiling panel and place it on the hook-on carrier or on the adjacent ceiling panel.
6. Hook securing element U 1073 A close to the front side at the longitudinal gap between ceiling plate and adjacent ceiling plate, thus securing both plates.
7. Slide securing element horizontally into the direction of Z profile U 1005 A as far as possible. The securing screw visible from underneath must be placed in the middle of the horizontal Z profile edge.
8. Tighten securing screw M4 by hand with Allen wrench SW 2.5.
9. Check the joint for perpendicularity and uniform width; if necessary, readjust the hook-on carrier to the required axial dimension.
10. Determine the length of the pre-cut shim in the border area. In doing so, take into account the two different types [panels with suspension bracket AS6 or with Z-edge AS3].
11. Cut the pre-cut shim using electric sheet shears and deburr the cutting edges.
12. Insert the pre-cut shim and the cutting edge into the F-lip of the perimeter trim profiles.

DISASSEMBLY OF THE CEILING PANELS

1. Wear clean cotton gloves.
2. Unscrew securing element U 1073 A.
3. Lift the adjacent panel of the ceiling panel to be dismantled.
4. Lift the ceiling panel to be dismantled, remove it using the hook-on edge [AS6] and lower it.
5. Carefully lower the adjacent ceiling panel.
6. Put the ceiling panel down and store it protected against damage.

CEILING
LIGHTING
AMBIENCE

durlum GmbH | An der Wiese 5 | D-79650 Schopfheim

T +49 (0) 76 22 | 39 05-0
F +49 (0) 76 22 | 39 05-42
E info@durlum.com
I durlum.com